

2005 Ford GT V8-5.4L SC

Vehicle > Body and Frame > Doors, Hood and Trunk > Doors > Front Door > Diagrams > Exploded Views

FRONT DOOR HANDLES, LOCKS AND LATCHES - EXPLODED VIEW


501-14 Handles, Locks, Latches and Entry Systems

2005 Ford GT

REMOVAL AND INSTALLATION

Procedure revision date: 10/18/2005

Front Door Handles, Locks and Latches – Exploded View



N0047371

Item	Part Number	Description
1	63219A64/ 63219A65	Door lock assembly
2	14A631/14A630	Electrical connector (LH/RH)
3	W500215-S437	Screw
4	6322404/ 6322405	Exterior door handle (LH/RH)
5	14A631/14A630	Electrical connector (LH/RH)
6	14018	Exterior door latch switch

7	14A631/14A630	Electrical connectors (LH/RH)
8	—	Door latch interior manual release cable (part of door lock assembly)
9	W708514-S900	Bolt (3 required)
10	63219A65/ 63219A64	Door latch assembly (LH/RH)
11	W620391-S36	Nut (2 required)
12	2522601/ 2522600	Interior door handle (LH/RH)
13	W703595-S300	Tie strap (2 required)

1. For additional information, refer to the procedures in this section.
